

Maintenance and Troubleshooting

Regular Maintenance

1. Clean the headset with a soft, dry cloth.
2. Wipe the lenses only with a microfiber cloth; avoid using chemicals.
3. Check the physical condition of the extinguisher simulator to ensure there is no damage.
4. Regularly charge the batteries, even if you do not use the device for an extended period.

WARNING: Always store the glasses in the case only when turned off.

The VR Headset Does Not Turn On

- Check if it is charged
- Hold the power button for at least 5 seconds
- Try connecting it to the charger, then turn it on again

The Extinguisher Simulator Does Not Respond

- Check the connection to the VR headset
- Restart the system
- Check if there is any physical obstruction to movement
- The batteries in the joysticks may drain; check them regularly

The Simulation Stutters or Freezes

- Restart the entire system
- Check if the headset has overheated
- Ensure there is sufficient free space for movement

Revision #1

Created 3 November 2025 16:02:15 by Admin

Updated 3 November 2025 16:02:25 by Admin